

# Installation Instructions for: CUSTOM SHOWER BASES



(WARRANTY WILL NOT APPLY IF THESE INSTRUCTIONS ARE NOT FOLLOWED)

- 1) Insure that all debris is cleared from the area. Make sure stud walls and sub floor are free of protruding nails.
- 2) Set shower base in place to insure that it is level, does not rock and fits snugly to studs on all sides.
  - A) It is important you check the level front to back and side to side. Put your level in each corner of base toward drain to insure that there is fall.
  - B) Use panel adhesive or silicone on bottom of base to adhere to sub floor.
  - C) You may need to use mortar mix or thin set under your base to insure the base is level and has full even contact with floor.
- 3) Install floor drain according to instructions provided with drain assembly.
- 4) Green board should come down covering the rubber flange 1/4" to 1/2" from base. Surround panels will come down to the floor of the shower base within 1/16"-1/8". See instructions provided with your threshold.

