



Pre-Installation Check List

IMPORTANT JOB SITE PREPARATION INSTRUCTIONS - PLEASE READ ALL INFORMATION THOROUGHLY – AMI INSTALLERS ARE NOT RESPONSIBLE FOR UNPREPARED JOB SITE CONDITIONS

Preparation by Customer/Contractor

Job site must be completely “install ready” prior to scheduled installation appointment. **AMI reserves the right to leave the jobsite if necessary preparation is not complete.** Installation of kitchen and/or bathroom products is a construction/renovation process and residual dust should be expected. Customer may want to drape or cover areas to help contain dust at their own discretions. AMI Installers lay drop cloths to help prevent as much dust as possible and leave the area in “broom clean” condition.

Countertops: Kitchen and bathroom cabinets must be level and secured to the walls and/or floor. All cabinetry and/or end panels must be completely and permanently installed prior to template and installation appointments. Job site area must be clean and clear of debris. Any item that may interfere with installation must be removed from the job site area prior to scheduled installation appointment. All fixtures requiring cutouts, faucets, cooktops, sinks, etc. must be present prior to installation. **No final plumbing hookup is provided by AMI.** Customer is responsible for the scheduling of a plumber, contractor, etc. needed to finalized the renovation project.

NOTE: Building and Plumbing codes may vary by location. AMI recommends contacting your local code officials for installation compliance standards. AMI is not responsible for building or plumbing code compliance standards for your project.

Countertop Overhang: Surface type and material thickness dictate the amount of overhang permitted on a countertop. Solid Surface countertops can support an overhang of 6” without additional brackets or corbels. However, at least 70% of the total countertop must be supported by cabinets, an island, knee wall, etc. All overhangs in excess of 6” will require corbels or brackets. All corbels and support brackets must be installed prior to installation. New or existing cabinets must be structurally sound to withstand the weight of the countertop.

Shower Bases and Wall Panels: Preparation of floor location for shower base is crucial to ensure a successful installation of shower base or complete shower. **FLOOR MUST BE LEVEL, CLEAN AND STRUCTURALLY SOUND.** Rough Plumbing must be installed prior to installation of shower base. AMI shower bases accommodate a 2” drain pipe with a 5” to 6” hole or 8” x 8” square hole for square drains around drain pipe. **AMI DOES NOT PROVIDE PLUMBING WORK.** A licensed plumber (if required by local code) should provide all plumbing services necessary (drain hookup, shower controls, etc.).

Shower bases are installed stud to stud prior to drywall/cement board. Remodel projects require existing drywall/cement board be removed up to 36” from sub floor prior to shower base installation. Complete showers including the shower base, wall panels and any accessories, seats, shelves, etc. are installed in (2) appointments as follows:

1. First appointment consists of shower base installation only. Job site must be fully prepared and “install ready” prior to scheduled appointment date.
2. **Preparation for final installation must be completed in full by customer/contractor.** All drywall/cement board must be installed leaving the bottom 36” open to install shower base. Rough in shower heads and controls must be installed. All support bracing for seats, grab bars, etc. must be in place prior to second scheduled appointment date.
3. In the event of a (1) day complete shower install, there must be someone available to install the drywall immediately following the shower base installation unless other approved arrangements have been made with AMI.

Unexpected Site Conditions: In most cases AMI templaters/installers are able to review conditions that may need addressed at the time of template. Occasionally, however, certain conditions are discovered that must be addressed before installation can be completed. Such conditions may require additional labor or material costs and rescheduling of installation.

Installation Approval Sign Off: Customer or designated decision maker must be present at time of installation. Work order showing material and services completed require a signature upon completion.

Notes:-

I have read and understand the information contained herein:

Customer Name (Please Print)

Date

Customer Signature

Date

Pre-Installation Check List

JOB SITES MUST BE INSTALL READY. UNPREPARED JOB SITE CONDITIONS WILL BE RESCHEDULED AND BILLED \$100 PER HOUR FOR TIME, WAGES, ADDITIONAL LABOR/MATERIALS. AMI RESERVES THE RIGHT TO LEAVE JOBSITE IF NECESSARY PERPARATION IS NOT COMPLETE.

COUNTERTOPS AND/OR SHOWERS

	JOB SITE IS CLEAN AND FREE OF DEBRIS
	FLOOR IS LEVEL, CLEAN AND STRUCTURALLY SOUND
	CABINETS ARE PERMANENTLY INSTALLED
	ROUGH PLUMBING IS INSTALLED – AMI SHOWER BASES ACCOMMODATE A 2” DRAIN PIPE WITH A 5-6” HOLE AROUND DRAIN PIPE. SQUARE DRAINS NEED A 8” SQUARE HOLE
	WALL BOARD AT IS REMOVED AT LEAST 36” FROM FLOOR IN SHOWER AREA – SHOWER BASE INSTALLATION IS STUD TO STUD
	ALL FIXTURES REQUIRING CUTOUTS ARE AT JOB SITE – SINKS, FAUCETS, ETC.
	SUPPORT BRACING FOR SEATS, GRAB BARS, ETC. MUST BE INSTALLED IN SHOWER AREA PRIOR FINAL INSTALLATION DATE
	SCHEDULE YOUR PLUMBER FOR FINAL HOOK UP – AMI DOES NOT PROVIDE PLUMBING